



## Operating Guide

操作指南

操作指南

### FCB-RECN

### FCB-RETN

Original Pet Fountain - 1.5 Litres

經典款寵物噴泉飲水器 - 1.5 公升

经典款宠物喷泉饮水器 - 1.5 公升



protect. teach. love:

Please read this entire guide before beginning

請在開始使用產品前閱讀本指南全文

請在使用之前全面閱讀本指南

Hereinafter Radio Systems Corporation and any other affiliate or Brand of Radio Systems Corporation may be referred to collectively as "We" or "Us".

## IMPORTANT SAFETY INFORMATION

Explanation of Attention Words and Symbols used in this guide

### **⚠ WARNING**

**WARNING** indicates a hazardous situation which, if not avoided, could result in death or serious injury.

### **CAUTION**

**CAUTION**, used without the safety alert symbol, indicates a hazardous situation which, if not avoided, could result in harm to your pet.

### **NOTICE**

**NOTICE** is used to address safe use practices not related to personal injury.

### **⚠ WARNING**

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock and/or injury to persons, including the following:

- To reduce the risk of injury, close supervision is necessary when an appliance is used by or near children.
- To protect against electric shock, do not place Power Cord or plug in water or other liquids.
- Only use attachments recommended or sold by the manufacturer.
- Do not use outdoors. **FOR INDOOR HOUSEHOLD USE ONLY.**
- Do not unplug by pulling on Power Cord. To unplug, grasp the plug, not the Power Cord.
- Do not operate any appliance if it has a damaged Power Cord or plug, or if it is malfunctioning or has been damaged. Call Customer Care Centre immediately for further instructions.
- For a portable appliance - To reduce the risk of electrical shock, do not place or store an appliance where it can fall or be pulled into a tub or sink.
- Always unplug any appliance when not in use, before putting on or taking off parts and before cleaning. Never pull on the electrical Power Cord to remove the plug from the wall outlet.
- Do not use an appliance for anything other than its intended use.
- If the plug of this device gets wet, turn off the electricity to that outlet. Do not attempt to unplug.
- Examine this appliance after installation. Do not plug in if there is water on the Power Cord or plug.

**CAUTION**

- Do not allow pets to chew on or swallow any parts. If you are concerned about the Power Cord, purchase a cord conduit (a hard plastic protector) at any hardware store to protect the Power Cord.
- The Pet Fountain parts are BPA-FREE. However, some animals have been known to be sensitive to plastic food and water containers. If your animal shows signs of an allergic reaction to the plastic, please discontinue use until you have consulted with your veterinarian.

**NOTICE**

- The Pet Fountain is intended to run continuously (always plugged into electricity), as long as the water level is maintained and the Pet Fountain is cleaned regularly. Be sure to check the Pet Fountain regularly to help prevent damage to the Pump, as the water may get consumed or evaporate causing the Pump to run dry.
- Do not attempt repairs on the Motor yourself.
- To avoid the possibility of the plug or outlet getting wet, the outlet should always be above the level of the Pet Fountain.
- If an extension cord is necessary, an extension cord with a proper rating should be used.
- The electrical use of this appliance is 2.5 watts.
- Do not use appliance for anything other than intended use. The use of attachments not recommended or sold by the manufacturer may cause an unsafe condition. Do not modify the unit.
- Do not install or store appliance where it will be exposed to weather or temperatures below 4.5° C.
- Read and observe all important notices listed on the appliance and in the packaging.

**SAVE THESE INSTRUCTIONS**


Thank you for choosing the PetSafe® Brand. You and your pet deserve a companionship that includes memorable moments and a shared understanding together. Our products and training tools enhance the relationship between pets and their owners. **If you have any questions about our products or training your pet, please visit our website at [www.petsafe.net](http://www.petsafe.net) or contact our Customer Care Center at +86 (0) 755 2671 5353.**

To get the most protection out of your warranty, please register your product within 30 days at [www.petsafe.net](http://www.petsafe.net). By registering and keeping your receipt, you will enjoy the product's full warranty and should you ever need to call the Customer Care Center, we will be able to help you faster. Most importantly, your valuable information will never be given or sold to anyone. Complete warranty information is available online at [www.petsafe.net](http://www.petsafe.net).


## Table of Contents

Components .....	5
Features .....	5
Key Definitions .....	6
Operating Instructions .....	7
Pet Fountain Disassembly & Cleaning .....	8
Pump Maintenance .....	9
Pet Fountain Reassembly .....	10
The Pet Fountain and Your Environment .....	11
General Tips .....	11
Warranty and Customer Care .....	12
Compliance .....	12
Important Recycling Advice .....	12
Terms of Use and Limitation of Liability .....	13

# Components



# Features



## Key Definitions

**Bowl:** The Bowl is the foundation of the Pet Fountain. It features two handles on either side of the Pet Fountain as well as a “cord channel” to hide the electrical power cord from view.

**Housing:** Water is pumped up through the Housing to cycle through the Charcoal Filter and out the spout to create a waterfall into the Bowl.

**Housing Lid:** The Housing Lid snaps in place over the Housing, keeping pets out of the Charcoal Filter.

**Charcoal Filter:** The 3-layer Charcoal Filter is made with granulated carbon derived from coconut shells. The Charcoal Filter absorbs bad tastes and odors as the water passes through and helps keep the water tasting fresh and more appealing to pets.

**Pre-Filter:** This is a small intake grate which catches large particles such as hair, debris, and kibble before they reach the Charcoal Filter.




**Flow Control Knob:** The knob attaches to the Pump and adjusts the rate of water flow. The Flow Control Knob can be removed by taking apart the Pump (See “Pump Maintenance” section for detailed instructions).

**Pump (Motor):** The small aquarium Pump can be partially dismantled for cleaning. THE PUMP IS NOT DISHWASHER SAFE! Remove Pump from the Pet Fountain before cleaning (See “Pump Maintenance” section for detailed instructions). The Pump also features a removable In-Line Plug for easy attachment and removal.

# Operating Instructions

**Important:** DO NOT RUN DRY - FOR INDOOR USE ONLY. Pet Fountain will come fully assembled and ready for use.

1. As with any electrical device, check the electrical power cord for any tears or damage before use.
2. Make sure the In-Line Plug is connected. When connected properly the silver tip is not showing.
3. Remove the Housing by pressing the side tabs and lifting up. Inspect the inside of the Pet Fountain to ensure Pump is securely attached. Snap Housing back into place (**Fig. 1**).
4. Remove the Housing Lid and set aside.
5. Insert the Charcoal Filter. The Charcoal Filter fits diagonally into the two triangular slots located inside the Housing. The Charcoal Filter fits narrow side down, with the black side facing the front of the Pet Fountain towards the spout. The Charcoal Filter will slide easily into place, but make sure it is pushed all the way down (**Fig. 2 & 3**).



Charcoal Filter

**Important:** Rinse the Charcoal Filter thoroughly under cool water before placing in the Pet Fountain. This will remove any loose charcoal dust, which is harmless. A small amount of charcoal dust may be released for the life of the Charcoal Filter. This is normal and is not harmful to your pet.

6. Fill the Bowl with water. Replace the Housing Lid.
7. Place Pet Fountain in desired location. Do not pick up a full Pet Fountain by the Housing. Only pick up the Pet Fountain by placing both hands underneath the base of the Pet Fountain and grip the sidewalls for a sturdy hold. Important: To protect your floor always use a protective mat such as a towel or water-resistant placement. This will help protect your floor from any splashing or spills caused by your pet.
8. Before you plug in the Pet Fountain, make sure the electrical power cord and your hands are dry. Plug the Pet Fountain into a standard electrical wall outlet.
9. Set your desired flow rate with the Flow Control Knob, which is located to the right of the receiving ramp inside the Bowl. When the Flow Control Knob is in the 10 o'clock position, flow is at its lowest. When the Flow Control Knob is in the 2 o'clock position, flow is at its highest.
10. Add water to the Bowl as needed. Do not let the water level fall below the Flow Control Knob or you may risk Pump failure. Replacement Pumps are sold separately by contacting the Customer Care Centre at [asiacc@petsafe.net](mailto:asiacc@petsafe.net).

# Pet Fountain Disassembly & Cleaning


**Important:** Pet Fountain must be cleaned to continue working normally.

**CHARCOAL FILTER:** The Charcoal Filter should be changed every two to four weeks.

1. Replace the Charcoal Filter more frequently when using the Pet Fountain for multiple pets or pets that produce a lot of saliva.
2. The Charcoal Filter is an added feature of the Pet Fountain. The use of a filter is not required for normal operation, but using a filter will keep the Pet Fountain water cleaner.
3. The Charcoal Filter may be rinsed out when the Pet Fountain is cleaned. Never wash the filter with soapy water, as you will not be able to remove the soap residue.



**PET FOUNTAIN:** Clean the Pet Fountain once a week.

1. Unplug the Pet Fountain and disconnect the In-Line Plug.
2. Remove Housing Lid and remove the Charcoal Filter.
3. Empty the water out of the Pet Fountain.
4. Remove the Housing by pressing in the side tabs and lifting up (**Fig. 4**).



**Important:** The Flow Control Knob is attached to the Pump. Do not attempt to remove the Pump by pulling on the Flow Control Knob as this can damage or break the Pump.

5. Remove the Pump from its cavity by placing your index finger behind Pump and gripping the bottom with your thumb (**Fig. 5**).
6. Lift the Pump straight up – this may require slight force until the suction cups release.
7. Next, remove the Pump from the Pet Fountain by disconnecting the In-line Plug and disengaging the rubber gasket (**Fig. 6**). Pull the In-line Plug up through the hole located next to the Pump. Clean away any hair, debris or kibble that may have accumulated around the Flow Control Knob and the Faceplate of the Pump.
8. Once the Pet Fountain is completely disassembled you will have 3 plastic parts.




9. Clean the Pet Fountain plastic parts with warm water and soap. You can also put the Pet Fountain in the top rack of the dishwasher. Remove the Pump before placing the Pet Fountain in the dishwasher. **DO NOT PLACE PUMP IN DISHWASHER!** If possible, it is recommended that you turn down the heat of the water inside the dishwasher. The Pet Fountain may also be cleaned with a diluted vinegar solution (20% White Vinegar and 80% Water). Be sure to rinse thoroughly with fresh water.







10. If you have trouble reaching certain spots or hard-to-reach corners, try using a cotton swab or purchase the Drinkwell® Cleaning Kit, a 3-Piece Brush kit. To purchase a Cleaning Kit, visit our website at [www.petsafe.net](http://www.petsafe.net) to locate a retailer near you or contacting the Customer Care Centre at [asiacc@petsafe.net](mailto:asiacc@petsafe.net).

## Pump Maintenance


**Important:** Cleaning the Pump is essential to the longevity of the Pet Fountain, as well as the cleanliness of the water. Clean the Pump every two weeks. Warranty may be voided if the Pump's motor is not cleaned regularly.



1. Remove Pump from the Pet Fountain as explained in the "Pet Fountain Disassembly and Cleaning" section.
2. Once the pump is out of the Pet Fountain, with your thumb and forefinger, gently squeeze on either side of the Faceplate, and pull it off. It may be necessary to insert a fingernail into the seam of the Faceplate to pry it off (**Fig. 7 & 8**).
3. Next, you will want to remove the Intake Plate by placing your fingernail underneath the small lip located on the narrow side of the tear drop shaped Intake Plate Pull-Tab and pull it out (**Fig. 9**).
4. Once the Intake Plate is removed, you can also remove the Impeller (white, 3-bladed propeller) which is held in place magnetically. To remove the Impeller, use a fingernail to get underneath a blade and lift out (**Fig. 10**).





5. Once the Pump is disassembled you can clean the parts with warm water and soap. Use a cotton swab or the “motor brush” from the Drinkwell® Cleaning Kit to get into the Pump’s motor cavity and remove any build-up (**Fig. 11**). For added disinfecting and hard water removal, clean the Pump’s motor with a diluted vinegar solution (20% White Vinegar and 80% Water). Be sure to rinse thoroughly with fresh water.
6. Once the parts are clean you can reassemble the Pump for use.
  - a) Replace the Impeller.
  - b) Replace the Intake Plate.
  - c) Replace the Faceplate with the Flow Control Knob attached to it.

**Fig. 11**

## Pet Fountain Reassembly

1. Replace the Pump by aligning the unit into its fitted space inside the Bowl (**Fig. 12**). The suction cups on the Pump should be facing down and the Flow Control Knob facing into the Bowl. Gently push down to engage suction cups.
2. Thread the In-Line Plug of the electrical power cord through the hole located next to Pump and push the rubber gasket firmly into the hole. To insure the Pet Fountain Bowl is stable, run the electrical power cord along the “cord channel” and through the notch in the base of the Pet Fountain (**Fig. 13**).
3. Attach the Housing by sliding the cutout in the wall of the Housing down over the Flow Control Knob. The Housing will click into place when the side tabs are inserted in the Bowl (**Fig. 14**).
4. Replace the Charcoal Filter, with the black side facing the front of the Pet Fountain towards the spout.
5. Fill the Bowl with water and replace the Housing Lid.
6. Place the Pet Fountain in desired location. Do not pick up a full Pet Fountain by the Housing. Only pick up the Pet Fountain by placing both hands underneath the base of the Pet Fountain and grip the sidewalls for a sturdy hold.  
**Important:** To protect your floor always use a protective mat such as a towel or water-resistant placemat. This will help protect your floor from any splashing or spills caused by your pet.
7. Before you plug in the Pet Fountain make sure the electrical power cord, the adaptor and your hands are dry. Connect the In-Line Plug and make sure no silver is showing then plug the adaptor into a standard electrical wall outlet.

**Fig. 12****Fig. 13****Fig. 14**

# The Pet Fountain and Your Environment

If you live in a humid environment and have problems with mold or algae, soak all Pet Fountain parts in a diluted vinegar solution (20% White Vinegar and 80% Water) for 10 minutes after regular cleaning. Also, pour the diluted vinegar solution into the Pump's motor cavity.

If you have hard water, small white mineral deposits may form on or inside the Pump. This can eventually prevent the Impeller from turning properly. To avoid replacement or damage to the Pump, please take the following precautions:

- Clean the Pump more frequently.
- Clean the Pump with a diluted vinegar solution weekly.
- Use bottled water instead of tap water.

---

## General Tips

- When being introduced to the Pet Fountain, your pet may be cautious of this new and unusual object. After beginning operation of your Pet Fountain, simply allow your pet to adjust at his or her own pace. Some pets may take several days or longer to begin use, while others will start right away.
- Your pet may prefer that the Pet Fountain be placed away from their normal feeding area. Try placing it in another location, such as a different area of the kitchen or in a bathroom or utility room.
- Add ice cubes to the bowl for refreshing, ice-cold running water!

## Warranty and Customer Care

This product has the benefit of a 1 (one) year limited manufacturer's warranty. This warranty does not cover damage from accidents, misuse or abuse. It also specifically excludes incidental or consequential damages as allowed by law. Loss of function as a result of lack of cleaning, debris or mineralization from "hard water" does not qualify under this warranty (Refer to cleaning instructions and environmental notes).

Details of the warranty applicable to this product and its terms can be found at [www.petsafe.net](http://www.petsafe.net) and/or are available by sending an email to: [asiacc@petsafe.net](mailto:asiacc@petsafe.net).

Please contact your local Customer Care Centre with any set-up or technical difficulties you experience, and if necessary to assist in the replacement of your product. For a listing of Customer Care Centres in your area, visit our website at [www.petsafe.net](http://www.petsafe.net).

---

## Compliance



This equipment complies with the EMC and Low Voltage Directives. Unauthorized changes or modifications to the product that are not approved by Radio Systems Corporation may violate EU regulations, could void the user's authority to operate the equipment, and will void the warranty.

The Declaration of Conformity can be found at:  
[http://www.petsafe.net/customer care/eu\\_docs.php](http://www.petsafe.net/customer care/eu_docs.php).

---

## Important Recycling Advice



Please respect the Waste Electrical and Electronic Equipment regulations in your country. This equipment must be recycled. If you no longer require this equipment, do not place it in the normal municipal waste system. Please return it to where it was purchased in order that it can be placed in our recycling system. If this is not possible, please contact the Customer Care Centre for further information.

# Terms of Use and Limitation of Liability

EN

T-CN

S-CN

## 1. **Terms of Use**

Use of this Product is subject to your acceptance without modification of the terms, conditions, and notices contained herein. Use of this Product implies acceptance of all such terms, conditions, and notices. If you do not wish to accept these terms, conditions, and notices, do not use this Product.

## 2. **Proper Use**

If you are unsure whether this is appropriate for your pet, please consult your veterinarian or certified trainer, contact our Customer Care Center, or visit our Web Site at [www.petsafe.net](http://www.petsafe.net). Proper use includes reviewing the entire Operating Guide provided with your product and any specific caution statements.

## 3. **No Unlawful or Prohibited Use**

This product is designed for use with pets only. This device is not intended to harm, injure, or provoke. Using this Product in a way that is not intended could result in violation of Federal, State, or local laws.

## 4. **Limitation of Liability**

In no event shall Radio Systems Corporation or any of its associated companies be liable for (i) any indirect, punitive, incidental, special or consequential damage and/or (ii) any loss or damages whatsoever arising out of or connected with the misuse of this Product. The Purchaser assumes all risks and liability from the use of this Product to the fullest extent permissible by law.

## 5. **Modification of Terms and Conditions**

Radio Systems Corporation reserves the right to change the terms, conditions, and notices under which this product is offered.

在下文中，Radio Systems Corporation 以及 Radio Systems Corporation 的其他任何聯屬公司或品牌可統稱為「我們」。

## 重要安全資訊

關於本指南中所用提醒文字與符號的說明

### 警告

警告表示存在危險狀況，若不予避免可能會導致死亡或嚴重傷害。

### 小心

小心不與安全提醒符號配合使用時，表示存在危險狀況，若不予避免可能會對您的寵物造成傷害。

### 注意

注意用於說明與人身傷害無關的安全使用方法。

### 警告

當使用本電器時，應始終遵循下列基本安全預防措施，以避免火災、觸電和/或人身傷害的危險：

- 為避免人身傷害的危險，當兒童使用本電器或在其附近活動時，務必仔細看護。
- 為防止觸電，請勿將電源線或插頭置於水或其他液體中。
- 僅可使用由製造商推薦或出售的附件。
- 不要在室外使用。僅可在室內作為家庭用途。
- 不要透過拉拽電源線而將其拔下。若要拔下電源線，請握住插頭，而不是電源線。
- 若某一部電器隨附的電源線或插頭已損壞，或是該電器發生故障或已損壞，請勿操作。應立即致電客戶服務中心以取得進一步的說明。
- 對於可攜式電器 - 為避免觸電的危險，請勿將本電器放置或貯存於可能會落入或拖入浴缸或水槽中的位置。
- 當不使用某一部電器時，或是在裝上或拆下部件之前，或在進行清潔之前，務必拔下該電器的插頭。切勿拉拽電源線而從牆上電源插座中拔下插頭。
- 不要將本電器用於除預期用途之外的其他任何用途。
- 若本電器的插頭被弄濕，請切斷供應給此電源插座的電力。而不要試圖拔下該插頭。
- 在本電器安裝完畢之後，應進行檢查。若電源線或插頭上沾水，請勿接通電源。

**小心**

- 不要讓寵物咀嚼或吞下任何部件。若您擔心電源線可能會受損，請在任何一間五金店購買一根防護線管（硬質塑膠防護管）來保護電源線。
- 飲水器部件不含雙酚 A。而據瞭解某些動物對塑膠制食物和水容器過敏。若您的寵物出現針對這種塑膠容器產生的過敏性反應症狀，則在找獸醫看病之前，請停止使用本電器。

**注意**

- 只要保持合適的水位並定期清潔飲水器，飲水器便可連續地運轉（始終接通電源）。務必定期檢查飲水器以防止水泵損壞，原因是水可能會耗盡或蒸發而使水泵空轉。
- 不要試圖自行修理馬達。
- 為避免插頭或電源插座被弄濕，電源插座應總是位於飲水器上方。
- 若有必要使用延長線，應採用具有適當額定值的延長線。
- 本電器的耗電量為 2.5 瓦特。
- 不要將本電器用於除預期用途之外的其他任何用途。若使用非由製造商推薦或出售的附件，可能會導致不安全狀況。請勿改動本電器。
- 不要將本電器安裝或貯存於會暴露在 4.5°C 以下之天氣或溫度的地方。
- 請閱讀並遵守本電器及包裝上載列的所有重要注意事項。

請保存使用說明書以備用

感謝您選擇 PetSafe® 品牌。您和您的寵物應享有一種包含難忘時刻和共同理解的友愛關係。我們的產品和訓練工具可增強寵物與其主人之間的關係。若您對於我們的產品或是訓練寵物有任何疑問，請造訪我們的網站 [www.petsafe.net](http://www.petsafe.net)，或是撥打電話 +86 (0) 755 2671 5353 連絡我們的客戶服務中心。

為透過產品保固獲得最大的保護，請於 30 天內造訪 [www.petsafe.net](http://www.petsafe.net) 註冊您的產品。您透過註冊並保管好您的收據，將享受產品的完整保固，而且如需打電話給客戶服務中心，我們將能夠為您提供更快捷的幫助。最重要的是，您的寶貴資訊決不會披露或出售給任何人。請造訪 [www.petsafe.net](http://www.petsafe.net) 線上取得完整保固資訊。

## 目錄

部件 .....	17
特點 .....	17
重要定義 .....	18
操作說明 .....	19
飲水器拆卸與清潔 .....	20
水泵日常保養 .....	21
飲水器重新組裝 .....	22
宠物喷泉饮水器与您的环境 .....	23
一般提示 .....	23
保固與客戶服務 .....	24
合規性 .....	24
重要的回收利用建議 .....	24
使用條款和責任限制 .....	25




# 部件


EN

T-CN

S-CN



## 特點



## 重要定義

**水盆：**水盆為寵物噴泉飲水器的基座。它在寵物噴泉飲水器的每一邊均有兩個把手，並採用電線收納槽以遮蔽電源線。

**機體：**水從這裡向上泵送並穿過機體，然後流入活性炭濾芯內進行循環，接著從噴嘴噴出以產生瀑布似的水流，最後流入水盆中。

**機體頂蓋：**機體頂蓋在機體上卡到位，以使寵物無法觸碰到活性炭濾芯。

**活性炭濾芯：**它是一種包含由椰子殼製成的粒狀碳的三層碳濾芯。活性炭濾芯可在水從其中流過時吸收不良味道與氣味，並有助於保持水的新鮮味道，從而對寵物更具有誘惑力。

**預過濾網格片：**這是一種小的進水柵，可在毛髮、碎屑和狗食等大的顆粒物進入活性炭濾芯之前將它們卡住。



**水流調節旋鈕：**該旋鈕裝在水泵上，可用於調節水流速率。水流調節旋鈕可透過拆開水泵而取下（請參閱「水泵日常保養」一節以取得詳細說明）。

**水泵（馬達）：**它是一種小的水族箱用水泵，可部分地拆卸以進行清潔。洗碗機不可用於該水泵！在清潔該水泵之前，請從寵物噴泉飲水器上拆下它（請參閱「水泵日常保養」一節以取得詳細說明）。該水泵還包含一個易於連接和拔出的卸除式內聯插頭。

# 操作說明

**重要事項：**飲水器禁止空轉 - 僅限室內使用。寵物噴泉飲水器將組裝完好，隨時可以使用。

1. 與其他任何電氣裝置一樣，在使用本電器之前，請檢查電源線有無任何撕裂或破損之處。
2. 確保內聯插頭已連接。當它連接妥當時，不會顯露鍍銀尖端。
3. 向內推壓側面鎖扣，並向上提起機體以將其拆下。請檢查寵物噴泉飲水器內部以確保水泵已牢固地連接。然後將機體放回並卡到位（圖 1）。
4. 拆下機體頂蓋，並將其擱在一邊。
5. 插入活性碳濾芯。活性碳濾芯將沿對角線裝入機體內兩個三角形插槽中。在裝入活性碳濾芯時，讓窄的一面朝下，並使黑色面朝向寵物噴泉飲水器的正面（朝向噴嘴）。活性碳濾芯將輕鬆地滑動到適當位置，但需確保將它一直推到底（圖 2 和 3）。



**重要事項：**應先把活性碳濾芯放在涼水下徹底沖洗乾淨，然後將其置於寵物噴泉飲水器中。這將清除所有鬆動的碳塵（對身體無害）。在活性碳濾芯的使用壽命期內，可能會釋放少量碳塵。這是正常情況，不會傷害到您的寵物。

6. 給水盆內注滿水。然後把機體頂蓋放回原處。
7. 將寵物噴泉飲水器置於所需位置。不要透過提拉機體拿起整個寵物噴泉飲水器。僅可透過把雙手放在寵物噴泉飲水器的底座下方來抬起飲水器，並抓緊側壁以保持穩固。重要事項：為保護地板免受損害，請務必使用保護墊，如毛巾或防水餐墊。這將有助於防止因寵物之緣故使水飛濺或滴落到地板上。
8. 給寵物噴泉飲水器接通電源之前，請確保電源線以及您的雙手均為乾的。然後將寵物噴泉飲水器的插頭插入標準的牆上電源插座中。
9. 利用位於水盆內接水斜面板右邊的水流調節旋鈕來設定所需流速。當水流調節旋鈕設於 10 點位置時，流速最低。當水流調節旋鈕設於 2 點位置時，流速最高。
10. 可根據需要在水盆中添加水。不要讓水位降至低於水流調節旋鈕，否則可能導致水泵發生故障。備用水泵須另購，可傳送電子郵件至 [asiacc@petsafe.net](mailto:asiacc@petsafe.net) 聯絡客戶服務中心。

# 飲水器拆卸與清潔


**重要事項：**寵物噴泉飲水器須清洗乾淨以便繼續正常工作。

**活性炭濾芯：**活性炭濾芯應當每 2 至 4 週更換一次。

1. 若寵物噴泉飲水器用於多隻寵物或是產生大量唾液的寵物，應當更頻繁地更換活性炭濾芯。
2. 活性炭濾芯是寵物噴泉飲水器的一項附加功能。濾芯的使用並非飲水器維持正常運轉所必需的，但可以讓寵物噴泉飲水器中的水更潔淨。
3. 在清潔寵物噴泉飲水器時，可能會把活性炭濾芯沖洗掉。切勿用肥皂水清洗濾芯，否則將無法去除肥皂殘留物。


**寵物噴泉飲水器：每週清潔一次寵物噴泉飲水器。**

1. 拔出寵物噴泉飲水器的插頭，然後拔下內聯插頭。
2. 拆下機體頂蓋，並取出活性炭濾芯。
3. 將寵物噴泉飲水器內的水倒空。
4. 向內推壓側面鎖扣，並向上提起機體以將其拆下（圖 4）。




**重要事項：**水流調節旋鈕裝在水泵上。請勿嘗試透過拉拽水流調節旋鈕而拆下水泵，否則可能會導致水泵損壞或破裂。

5. 把食指塞入到水泵後面並用拇指抓緊其底部，以從相應的凹處將水泵拆下（圖 5）。
6. 將水泵一直往上提起－這可能需要稍微用力，直到吸盤脫離為止。
7. 接著從寵物噴泉飲水器上拆下水泵，方法是拔下內聯插頭並使橡膠墊圈脫離（圖 6）。向上拉動內聯插頭，並使其穿過緊鄰著水泵的孔。清除掉可能已在水流調節旋鈕和水泵進水面板周邊聚積的所有毛髮、碎屑或狗食。




8. 將寵物噴泉飲水器完全拆卸之後，即可取得 3 個塑膠部件。



9. 用溫水和肥皂清潔寵物噴泉飲水器的塑膠部件。也可把寵物噴泉飲水器放置於洗碗機的頂架上。將寵物噴泉飲水器置於洗碗機上之前，請拆下水泵。水泵不可放入洗碗機內！建議盡可能調低洗碗機內的水溫。也可用經稀釋的醋溶液（20% 白醋與 80% 水相混合）清潔寵物噴泉飲水器。請務必用清水徹底沖洗。
10. 若您夠不著飲水器上的某些部位或是難以夠到角落處，請嘗試使用棉籤或是購買 Drinkwell® 清潔套裝（三件式清潔刷套裝）。如需購買清潔套裝，請造訪我們的網站 [www.petsafe.net](http://www.petsafe.net) 找到您附近的零售店，也可傳送電子郵件至 [asiacc@petsafe.net](mailto:asiacc@petsafe.net) 聯絡客戶服務中心。



# 水泵日常保養

**重要事項：**為確保寵物噴泉飲水器的使用壽命以及潔淨的水質，必須對水泵進行清潔。應當每 2 週清潔一次水泵。若水泵馬達未定期加以清潔，保固可能會失效。




1. 請按照「寵物噴泉飲水器拆卸與清潔」一節中的說明從寵物噴泉飲水器上拆下水泵。

2. 從寵物噴泉飲水器中取出水泵之後，即用拇指和食指輕輕地捏住進水面板的兩邊並向外拉動，以將其拔出。可能有必要把手指甲塞入進水面板的接縫內，以將其撬出（圖 7 和 8）。



3. 接著您將需要拆下進水面板，方法是：把您的手指甲塞到小的唇狀物（位於淚滴形進水面板拉環上窄的一側）下方，並將其拉出（圖 9）。




4. 在取出進水面板之後，也可拆下透過磁力

固定到位的葉輪（白色，三瓣式葉輪片）。

若要拆下葉輪，請把手指甲塞入一個葉片下方，然後將葉輪提起並取出（圖 10）。

5. 一旦將水泵拆卸完畢，即可用溫肥皂水清潔其部件。可用棉籤或是 Drinkwell® 清潔套裝中的馬達清洗刷清潔水泵馬達內腔，並清除所有聚積物（圖 11）。如需另外進行消毒並去除硬水，請用經稀釋的醋溶液（20% 白醋與 80% 水相混合）清潔水泵馬達。請務必用清水徹底沖洗。




6. 一旦各部件清潔完畢，即可重新組裝水泵以供使用。

a) 把葉輪放回原處。



b) 把定子放回原處。

c) 把進水面板放回原處，並與水流調節旋鈕相連。



## 飲水器重新組裝

1. 把水泵放回原處，方法是將該裝置對準水盆內尺寸合適的空間 並放入其中（圖 12）。水泵上的吸盤應當朝下，而水流調節旋鈕則朝向水盆。輕輕地往下按壓以使吸盤接合。
2. 使電源線的內聯插頭穿過緊鄰著水泵的孔，並用力將橡膠墊圈推入孔內。為確保寵物噴泉飲水器上的水盆能穩定地運轉，請將電源線塞進電線收納槽中，並穿過寵物噴泉飲水器底座上的凹槽（圖 13）。
3. 透過以下方式連接機體：將機體壁上的密封凹槽向下滑動到水流調節旋鈕上方。當側面鎖扣插入到水盆中時，機體將卡到位（圖 14）。
4. 把活性炭濾芯放回原處，讓黑色面朝向寵物噴泉飲水器的正面（朝向噴嘴）。
5. 給水盆內注滿水，然後把機體頂蓋放回原處。
6. 將寵物噴泉飲水器置於所需位置。不要透過提拉機體拿起整個寵物噴泉飲水器。僅可透過把雙手放在寵物噴泉飲水器的底座下方來抬起飲水器，並抓緊側壁以保持穩固。重要事項：為保護地板免受損害，請務必使用保護墊，如毛巾或防水餐墊。這將有助於防止因寵物之緣故使水飛濺或滴落到地板上。
7. 給寵物噴泉飲水器接通電源之前，請確保電源線、變壓器以及您的雙手均為乾的。連接內聯插頭，並確保未顯露任何鍍銀部分，然後將變壓器的插頭插入標準的牆上電源插座中。



# 宠物喷泉饮水器与您的环境

如果您的居住环境湿度大，存在霉菌和水藻等问题，则在正常清洁后将所有宠物喷泉饮水器部件浸泡在稀释的醋溶液（20% 的白醋和 80% 的水）中约 10 分钟。并且也要将稀释的醋溶液倒入马达内腔。

如果您用的是“硬水”，水泵上面或内侧可能开始出现少量白色矿物沉淀。这最终会影响叶轮的正常旋转。为了避免更换或损坏水泵，请采取下列预防措施：

- 更频率地清洁水泵。
- 使用稀释的醋溶液每周清洁水泵。
- 使用瓶装水而非自来水。

---

## 一般提示

- 您的寵物經引導使用飲水器時，可能對這個新奇的物體十分小心。在飲水器開始運轉之後，只需讓您的寵物按照它的步調進行調整即可。某些寵物可能需要幾天或更長的時間才開始使用飲水器，而有些寵物會馬上開始使用。
- 您的寵物可能更喜歡飲水器放置於遠離其正常攝食區域的地方。請嘗試把飲水器放在另一個位置，例如廚房中的其他區域或是盥洗室或雜用間。
- 可在水盆中加一些冰塊，以使自來水變得清爽而冰涼！

## 保固與客戶服務

本產品享有製造商提供的一 (1) 年有限保固。該保固不適用於因意外、誤用或濫用行為所致的損害。它還在法律允許之範圍內明確地排除了偶發性或後果性損害。因未進行清潔、碎片或硬水的礦化作用所致的功能喪失不在本保固範圍之內（請參閱清潔指示和環境說明）。

如需取得關於適用本產品之保固及其條款的詳細資訊，可造訪 [www.petsafe.net](http://www.petsafe.net) 及/或傳送電子郵件至 [asiacc@petsafe.net](mailto:asiacc@petsafe.net)。

請聯絡當地的客戶服務中心以解決您所遇到的任何安裝或技術難題，以及在必要時獲得協助來更換產品。如需取得您所在地區的客戶服務中心清單，請造訪我們的網站 [www.petsafe.net](http://www.petsafe.net)。

---

## 合規性

 本設備符合電磁相容性 (EMC) 和低電壓指令的要求。若在未獲得授權之情形下對本產品作出未經 Radio Systems Corporation 批准的變更或改動，可能會違反歐盟法規，而且可能導致使用者操作本設備之權限失效，並會使本保固失效。

如需查看「符合性聲明」，可造訪：  
[http://www.petsafe.net/customer-care/eu\\_docs.php](http://www.petsafe.net/customer-care/eu_docs.php)。

---

## 重要的回收利用建議



請遵守您所在國家/地區實行的廢電機電子設備規定。務必將本設備回收再利用。若您不再需要本設備，請勿將它棄置於標準的市政廢物處理系統中。請把它返還至您最初購買本產品的地方，這樣它可進入到我們的回收再利用系統。若您無法這樣做，請聯絡客戶服務中心以取得進一步的資訊。



# 使用條款和責任限制

## 1. 使用條款

若要使用本產品，應當接受本文所載之條款、條件和通知，而不對其作出修改。使用本產品即意味著您接受所有此等條款、條件和通知。若您不願接受這些條款、條件和通知，請勿使用本產品。

## 2. 正確使用

若您不確定本產品是否適合您的寵物，請諮詢獸醫或持有證書的馴獸師，或是連絡我們的客戶服務中心，或造訪我們的網站 [www.petsafe.net](http://www.petsafe.net)。正確使用包括仔細閱讀產品隨附之「操作指南」的全文以及所有特定的警告聲明。

## 3. 不得用於非法或禁止的用途

本產品專門設計用於寵物。本裝置不可用於危害、傷害或激怒寵物。以非預期方式使用本產品可能會違反聯邦、州或當地法律

## 4. 責任限制

在任何情況下，Radio Systems Corporation 或其任何一間聯屬公司皆不對以下損害或損失承擔責任：(i) 任何間接性、懲罰性、偶發性、特殊性或後果性損害，及/或 (ii) 因誤用本產品所致或與之相關的任何損失或損害。購買者將在法律所允許之最大範圍內承擔與使用本產品有關的所有風險和責任。

## 5. 條款和條件之修改

Radio Systems Corporation 保留變更提供本產品時應遵循之條款、條件和通知的權利。

---

\* 已在美國專利暨商標局註冊

在下文中，Radio Systems Corporation 和任何其它附属公司或 Radio Systems Corporation 品牌都将统称为“我们”。

## 重要安全信息

本指南中使用的警示语和符号说明

### 警告

“警告”表示一种危险处境，如果不避免，会导致人员死亡或严重受伤。

### 小心

“小心”未与安全警告符号同时使用时，表示一种危险处境，如果不避免，可能会导致您的宠物受到伤害。

### 注意

“注意”用于指示不会导致人员受伤的正确做法。

### 警告

当使用电器时，应遵循基本的安全注意事项，以降低火灾、电击和/或人员伤害的风险，包括：

- 为避免受伤，靠近或由儿童使用电器时必须予以严格监督。
- 为避免电击，请勿将电源线或插头置于水或其他液体中。
- 仅使用由制造商推荐或销售的附件。
- 请勿用于户外。仅供室内家庭使用。
- 请勿抓住电源线拔下插头。在拔插头时抓住插头，而不是电源线。
- 请勿在电源线或插头破损时，或者其有故障或损坏时操作任何电器。请立即致电客服中心寻求进一步指示。
- 对于便携电器 - 为了降低电击风险，请勿将其置于会掉到或被拖入浴缸或水池中的位置。
- 在不用时、拆卸或安装部件以及清洁之前，请务必拔下电器插头。切勿通过拉拽电源线，从墙壁插座上拔下插头。
- 请勿将电器用于其他非预期目的。
- 如果设备插头湿了，请断开至该插座的电流。请勿尝试拔下插头。
- 安装好电器后进行检查。如果电源线或插头上有水，请勿连接。

**小心**

- 请勿让宠物咀嚼或吞噬任何部件。如果您担心电源线安全，则请在五金店购买一个电源线导管（硬质塑料保护壳）来保护电源线。
- 饮水器部件不含BPA（双酚丙基烷）。但有些动物被发现对塑料的食物和水容器过敏。如果您的宠物有对塑料过敏的症状，请暂停使用并咨询您的兽医。

**注意**

- 只要水位稳定且定期清洁，饮水器将持续运转（一直通电）。确保定期检查饮水器，避免损坏水泵，这是因为水会用完或挥发掉，造成水泵空转。
- 请勿试图自行修理马达。
- 为了避免弄湿插头或插座，插座应始终高于饮水器液位。
- 如有必要，请使用额定功率合适的延长线。
- 本电器的功率为 2.5 瓦。
- 请勿将电器用于其他非预期目的。使用非制造商推荐或销售的附件可能会有危险。请勿改装设备。
- 请勿将电器安装或储存于温度低于4.5° C的环境中。
- 阅读并遵守电器上和包装中列出的所有注意事项。

**请保存使用说明书以备用**

感谢您选择 PetSafe® 品牌。您和您的宠物值得拥有互相陪伴的难忘时刻和包容共识。我们的产品和训练工具将增进宠物和主人之间的关系。如果您对我们的产品和训练工具有任何问题，请查询我们的网站：[www.petsafe.net](http://www.petsafe.net)，或致电我们的客服中心：+86 (0) 755 2671 5353。


为了充分利用您的保修期，请于 30 日内在 [www.petsafe.net](http://www.petsafe.net) 注册您的产品。通过注册和保留你的收据，您将享受本产品的全部免费保修。如您致电客服中心，我们会更加及时地帮助您。最重要的是，我们绝不会将您的宝贵信息透露或出售给任何人。在 [www.petsafe.net](http://www.petsafe.net) 您可以找到完整的保修信息。

---


## 目录

组件 .....	29
特点 .....	29
重要定义 .....	30
使用说明 .....	31
饮水器拆卸与清洁 .....	32
水泵日常维护 .....	33
饮水器重新组装 .....	34
宠物喷泉饮水器与您的环境 .....	35
一般提示 .....	35
保修和客服 .....	36
合规性 .....	36
重要的回收利用建议 .....	36
使用条款及责任限制 .....	37

# 组件



# 特点



## 重要定义

**水槽：**水槽是宠物饮水器的基础。其在宠物饮水器任一侧有两个手柄，以及一个用以隐藏电源线的“电源线收纳槽”。

**外壳：**水经由外壳被泵抽至循环，通过活性炭滤芯并在喷嘴流出，形成一个水柱落入水槽中。

**外壳顶盖：**外壳顶盖卡入到外壳中，使宠物接触不到活性炭滤芯。

**活性炭滤芯：**三层炭过滤器里面是椰壳制成的炭粒。活性炭滤芯在水通过时会吸收异味，使水清新并吸引宠物。

**预过滤隔板：**这是一个小型进口格栅，用以阻挡大颗粒，如毛发、残渣和粗食，使其无法进入活性炭滤芯。



**水流调节旋钮：**该旋钮安装在水泵上，可调节水流大小。拆开泵可将水流调节旋钮取下（请参阅“水泵日常维护”一节了解详细说明）。

**水泵（马达）：**一个小型的水族水泵，可部分拆除进行清洁。此水泵不可放入洗碗机清洗！请在清洁之前从宠物饮水器上拆下水泵（请参阅“水泵日常维护”一节了解详细说明）。水泵还配备了一个可拆卸的内联插头以便安装和拆除。

# 使用说明

**重要：**切勿让饮水机空转 - 仅适于室内使用。宠物饮水机在购买时已安装好，可随时使用。

- 如同任何电器设备一样，在使用前检查电源线是否有破损。
- 确保已连接内联插头。正确连接后不会露出银质插头。
- 按侧调节阀并向上抬，取下外壳。检查宠物饮水机内部，确保水泵已固定好。将外壳装回到原位（见图 1）。
- 取下外壳顶盖并放到旁边。
- 插入活性炭滤芯。活性炭滤芯沿对角线置于外壳中的两个三角形卡槽中。放置活性炭滤芯时让窄边朝下，黑色一面对着宠物饮水机正面（向着喷嘴）。活性炭滤芯将轻松滑入到位，确保其完全推至下侧（见图 2 和 3）。



**重要：**在置于宠物饮水机中之前要用冷水彻底冲洗活性炭滤芯。这将清除所有脱落的无害炭粉。滤芯在寿命期内可能会一直释放少量活性炭。这是正常现象，对宠物无害。

- 给水槽注水。放回外壳顶盖。
- 将宠物饮水机放在合适的地方。请勿通过外壳来提起整个宠物饮水机。只可将双手放在宠物饮水机基座下面，并抓紧侧壁，握牢宠物饮水机。**重要：**为了保护地板，确保使用保护垫，如毛巾或防水垫。这将有助于防止宠物将水溅到地板上。
- 在给宠物饮水机通电前，确保电源线和您的手是干的。将宠物饮水机连接到标准的壁式电源插座。
- 在水槽中的接水斜面右侧有一个水流调节旋钮，用它设定合适的水流大小。当水流调节旋钮在 10 点钟方位时，水流最小。当其在 2 点钟方位时，水流最大。
- 根据需在水槽中加水。切勿让水位低于水流调节旋钮，否则可能损坏水泵。替换水泵另行购买，具体可通过 [asiacc@petsafe.net](mailto:asiacc@petsafe.net) 联系客服中心。

# 饮水器拆卸与清洁

**重要：**宠物饮水器必须清洁才能正常使用。

**活性炭滤芯：**活性炭滤芯应每二到四周更换一次。

1. 当宠物饮水器用于多个宠物或宠物唾液非常多时，应增加更换活性炭滤芯的频率。
2. 活性炭滤芯是宠物饮水器的增加功能。正常使用无需滤芯，但使用滤芯可以净化宠物饮水器中的水。
3. 在清洁宠物饮水器时可冲洗活性炭滤芯。切勿使用肥皂水清洗滤芯，因为肥皂残留很难清除。



**宠物饮水器：**每周清洁一次宠物饮水器。

1. 拔下宠物饮水器的插头，并断开内联插头。
2. 取下外壳顶盖，并取出活性炭滤芯。
3. 倒空宠物饮水器中的水。
4. 按侧调节阀并向上抬，取下外壳（见图 4）。

**重要：**将水流调节旋钮装到水泵上。切勿在取出水泵时拉动水流调节旋钮，因为这会损坏水泵。

5. 将食指放在水泵后侧，并用拇指握住底部，可从其内腔中取出水泵（见图 5）。
6. 竖直提起水泵 - 这可能需要用点力，直到吸盘脱离。
7. 然后断开内联插头并松开橡胶垫，从宠物饮水器中取出水泵（见图 6）。将内联插头从水泵旁的孔中拉出来。清除干净堆积在水流调节旋钮和水泵进水面板周围的所有毛发、残渣或粗食。


8. 在宠物饮水器完全拆卸后，您将得到 3 个塑料部件。
9. 使用温水和肥皂清洁宠物饮水器的塑料部件。您也可以将宠物饮水器放在洗碗机的顶层。在将宠物饮水器置于洗碗机中之前请取出水泵。切勿将水泵放入洗碗机！如果可能，建议您降低洗碗机中的水温。您也可以使用稀释的醋溶液（20% 的白醋和 80% 的水）清洁宠物饮水器。要确保用清水彻底冲洗。
10. 如果有些位置或角落够不到，则可以使用棉签或购买 Drinkwell® 清洁套件，即清洁刷三件套。若要购买清洁套件，请访问我们的网站 [www.petsafe.net](http://www.petsafe.net) 查找您附近的零售商或通过 [asiacc@petsafe.net](mailto:asiacc@petsafe.net) 联系我们的客服中心。





# 水泵日常维护

**重要：**清洁水泵对于宠物饮水器寿命以及水的清洁至关重要。每两周清洁一次水泵。如果未能定期清洁水泵马达，保修可能失效。




1. 按照“饮水器拆卸与清洁”一节的解释，从宠物饮水器上拆下水泵。

2. 将水泵取出宠物饮水器后，用拇指和食指轻轻捏住进水面板任一端，然后拉出。这可能需要在进水面板的接缝中插入手指甲将其撬开（见图 7 和 8）。




见图 7



见图 8


3. 然后，您需要将指甲伸到进水面板泪滴形拉环上的小唇片下面，并向外拉，取出进水面板（见图 9）。



见图 9

4. 取出进水面板后，您还可以拆下叶轮（白色，3 片式叶轮），叶轮靠磁性保持在原位。若要拆下叶轮，可将指甲伸到叶片下并往外拉（图 10）。

进水面板拉环




见图 10

5. 拆开水泵后，可以用温水和肥皂清洁其部件。使用棉签或 Drinkwell® 清洁套件中的“马达清洗刷”伸入水泵马达内腔并清除所有沉积物（见图 11）。为了提高消毒和硬水去除效果，请使用稀释醋酸溶液（20% 白醋和 80% 水）清洁水泵马达。要确保用清水彻底冲洗。

6. 清洁部件后可以重新组装水泵备用。



- 重新装好叶轮。
- 重新装好定子。
- 装回进水面板及水流调节旋钮。



见图 11

# 饮水器重新组装

1. 将装置对齐水槽中的安装位置，装回水泵（见图 12）。水泵上的吸盘向下，而水流调节旋钮面向水槽。轻轻下压，使其连接到吸盘上。
2. 将电源线的内联插头穿过水泵旁的孔，并将橡胶垫牢牢按到孔中。为了确保宠物饮水器的稳定，电源线应沿“电源线收纳槽”敷设，并穿过宠物饮水机基座内的凹槽（见图 13）。
3. 安装外壳时，在外壳壁中向下滑动密封，使其位于水流调节旋钮上方。当侧调节阀插入水槽中时，外壳即会卡入到位（见图 14）。
4. 放置活性炭滤芯时让黑色一面对应着宠物饮水机正面（向着喷嘴）。
5. 在水槽中加水并放回外壳顶盖。
6. 将宠物饮水器放在合适的地方。请勿通过外壳来拿取整个宠物饮水器。只可将双手放在宠物饮水机基座下面，并抓紧侧壁，握牢宠物饮水器。重要：为了保护地板，确保使用保护垫，如毛巾或防水垫。这将有助于防止宠物将水溅到地板上。
7. 在给宠物饮水器通电前，确定电源线、适配器和您的手是干的。连接内联插头并确保没有银色显露，然后将适配器插入一个标准的壁式电源插座。



# 宠物喷泉饮水器与您的环境

如果您的居住环境湿度大，存在霉菌和水藻等问题，则在正常清洁后将所有宠物喷泉饮水器部件浸泡在稀释的醋溶液（20% 的白醋和 80% 的水）中约 10 分钟。并且也要将稀释的醋溶液倒入马达内腔。

如果您用的是“硬水”，水泵上面或内侧可能开始出现少量白色矿物沉淀。这最终会影响叶轮的正常旋转。为了避免更换或损坏水泵，请采取下列预防措施：

1. 更频率地清洁水泵。
2. 使用稀释的醋溶液每周清洁水泵。
3. 使用瓶装水而非自来水。

---

## 一般提示

- 开始使用饮水器时，宠物可能会对这个新鲜事物感到好奇。起初，要允许宠物按自己的节奏适应饮水器。有些宠物可能需要几天或更久，而另一些则可能会立刻开始使用。
- 您的宠物可能更喜欢将饮水器放在远离正常喂食的地方。将其放在其他地方，如厨房的另一个位置，或者厕所或杂物间中。
- 在水槽中添加冰块以获得新鲜的冰冷流水！

## 保修和客服


本产品享受 1（一）年的有限厂家保修。该保修范围不包括意外、误用或滥用引起的损坏。它还特别排除了法律规定的连带或间接损坏。缺乏清洁以及“硬水”造成的碎屑或矿化引起的功能丧失不在保修范围内（参阅清洁说明和环保注意事项）。

本产品适用的保修详情及其条款可从 [www.petsafe.net](http://www.petsafe.net) 上获取，和/或发送电子邮件至 [asiacc@petsafe.net](mailto:asiacc@petsafe.net) 索取。

如有任何安装或技术问题，请联系当地的客服中心，并根据需要，更换产品。如需获得您所在地区客服中心的清单，请浏览我们的网站 [www.petsafe.net](http://www.petsafe.net)。

---

## 合规性


 本产品符合电磁兼容性（EMC）和低压指令。未经 Radio Systems Corporation 授权对产品进行改动或修改会违反欧盟法规，并导致用户失去操作本设备的资格，并会使保修失效。

合规声明地址：

[http://www.petsafe.net/customer care/eu\\_docs.php](http://www.petsafe.net/customer care/eu_docs.php)

---

## 重要的回收利用建议



请遵守贵国的废弃电气和电子设备规定。此设备必须回收处理。如果您不再需要此设备，请勿将其随意丢弃。请将其送回您购买此产品的商店，以便于将其投入我们的回收系统。如果无法做到这点，请联系客服中心以获取更多信息。

# 使用条款及责任限制

## 1. 使用条款

使用本产品您便已经无异议地接受了此处列举的使用条款和注意事项。使用本产品意味着接受了所有这些使用条款和注意事项。如果您不想接受这些使用条款和注意事项，请勿使用本产品。

## 2. 使用方式

如果您不确定本产品是否适用于您的宠物，请咨询您的兽医或有执照的训练师，与我们的客服中心联系或访问我们的网站：[www.petsafe.net](http://www.petsafe.net)。使用方式包含查阅随您的产品附带的完整操作指南以及任何具体的注意事项声明。

## 3. 禁止非法或不当使用

本产品是专为宠物使用而设计的。本设备不得用于伤害、致伤或挑衅。以非预期方式使用本产品可能会导致违反联邦、州或当地法律。

## 4. 责任范围

在任何情况下 Radio Systems Corporation 或其任何关联公司对如下事项不承担法律责任。(i) 任何间接的、惩罚性的、偶然的、特殊或间接损失；和 / 或 (ii) 由于误用本产品所导致的相应的任何损失或损害。购买者应在法律允许的最大范围内承担因使用本产品而带来的全部风险和责任。

## 5. 使用条款的修改

Radio Systems Corporation 保留更改使用条款以及本产品所提供之注意事项的权利。

---

\* 品牌已在美国专利商标局注册







protect. teach. **love\***

Radio Systems Corporation  
10427 PetSafe Way  
Knoxville, TN 37932  
(865) 777-5404  
**[www.petsafe.net](http://www.petsafe.net)**

400-1671-43/1

©2016 Radio Systems Corporation